EutroSORB®F

Phosphorus Filtration Technology

For use in aquatic systems to remove phosphorus and improve water quality.

Move person to fresh air. If person is not breathing, call 911 or an ambulance, then give artificial respiration preferably mouth-to-mouth, if possible. Call poison control center or doctor for further treatment advice. Take off contaminated clothing. Rinse skin immediately with plenty of water for 15 to 20 minutes. Call a poison control center or doctor for treatment advice.
Rinse skin immediately with plenty of water for 15 to 20 minutes.
Hold eyes open and rinse slowly and gently with water for 15 to 20 minutes. Remove contact lenses, if present, after the first 5 minutes, then continue rinsing eye. Call a poison control center or doctor for treatment advice.
Do not give milk or alcoholic beverages. Never give anything by mouth to an unconscious person. If symptoms persist, call poison control or doctor for further treatment advice.

KEEP OUT OF REACH OF CHILDREN

Read all FIRST AID and directions on label before use. Please consult the Safety Data Sheet (SDS) for additional information. Treatment with this product will not by itself make water potable. For applications in waters destined for use as drinking water, those waters must additional and separate potable water treatment.

PRECAUTION:

Avoid ingestion, inhalation, contact with eyes and skin. Avoid breathing dust as it may be irritating. In the case of dust formation use respirator with a P type filter. Wear and chemical-resistant gloves and eye protection when handling.

DIRECTIONS FOR USE

For best results, remove filters from bag and attach, suspend, or lay filters in flowing water sides where phosphorous removal is targeted. For site specific rates, treatment recommendations, contact SePRO Corporation at 1-800-419-7779.

STORAGE AND DISPOSAL

Do not contaminate water, food, or feed by storage or disposal.

Storage: Store in original container and keep closed. Store in a dry place.

Container Handling:

Non-refillable Container (non-rigid, any size): Do not reuse or refill this container. Completely empty bag into application equipment. Offer for recycling if available. If recycling is not available then dispose of empty bag in a sanitary landfill or by incineration, or if allowed by state and local authorities, by burning. If burned, stay out of smoke.

Warranty Disclaimer: SePRO Corporation warrants that this product conforms to the chemical description on the product label. Testing and research have also determined that this product is reasonably fit for the uses described on the product label. To the extent consistent with applicable law, SePRO Corporation makes no other express or implied warranty of fitness or merchantability, nor any other express or implied warranty and any such warranties are expressly disclaimed.

Misuse: To the extent consistent with applicable law, the buyer assumes responsibility for any adverse consequences if this product is not used according to its label directions. In no case shall SePRO Corporation be liable for any losses or damages resulting from the use, handling or application of this product in a manner inconsistent with its label.

For additional important labeling information regarding SePRO Corporation's Terms and Conditions of Use, Inherent Risks of Use and Limitation of Remedies, please visit http://seprolabels.com/terms or scan the image at the below.



EutroSORB is a registered trademark of SePRO Corporation Copyright ©2023 SePRO Corporation FPL20221114

SePRO Corporation 11550 North Meridian Street, Suite 600, Carmel, IN 46032, U.S.A.